

Fig. A - Front 3/4 View

DC 135 - Part No. 1414700

DC 205 - Part No. 1414702

Item	Cct Ref.	Description	Part No.	
			DC-135	DC205
-	-	Handle (not shown)	1414167	1414180
1	S1	Switch	1414160	1414160
-	-	Knob for item 1	1414161	1414161
2	RV1	Potentiometer	1414162	1414162
-	-	Knob for item 2	1414163	1414163
3	LP1	LED	1414164	1414164
4	S2	Switch	1414165	1414165
5	SK3	Socket (for plug see item 13 page 15)	1414166	1414166
6	SK1/2	Welding sockets	1404314	17242
-	-	Plug for item 6	1380444	1380441
7	-	Foot	1414168	1414168
8	-	Fan guard	1414169	1414185
9	-	Primary Cable Clamp	1414170	1414170




Fig. B. Side View

Item	Cct Ref.	Description	Part No.	
			DC135	DC205
1	L1	Inductor	1414171	1414181
2	R1	Resistor	1414172	1414172
3	M1/M2	Thyristor Module	1414173	1414182
-	-	Thermal Washer	1413393	1414195
-	TH2	Thermostat (Rectifier)	1414194	1414194
4	SH1	Shunt	1414174	1414193
5	TH1	Thermostat (Inductor)	1414179	1414179
6	PCB1	Printed circuit board	1414176	1414176
7	-	Socket	1414177	1414177
8	F	Fan	1414178	1414184
9	T1	Transformer	1414192	1414183
10	VR	Varistor	1414175	1414175
11	-	Housing	1414188	1414188
12	-	Plug	1414187	1414187
13	-	Remote control complete	14186	1414886