

Item	Description	Part Number	Item	Description	Part Number
1	Handle	66109	26	Insulator	66402
2	Lid	62500	27	Inductor	61963
3	Shelf	62483	28	Tx/Rectifier PCB	61329
4	LHS Panel	62349L	29	Thermal Switch 80C	65775
5	Control Panel Assembly	61339	30	Base	62009
6	uP Control PCB	61340	32	Thermal Switch 60C	65776
7	LCD Display PCB	61894	33	Primary Inverter PCB	61328
8	Control Panel	62011	34	Aux Tx	64637
9	Control Panel Label	66751	35	RHS Panel	62349R
10	Pot/Switch 100k	65192	36	Strain Relief	66061
11	Knob d29	66208	37	Fan	64182
12	Knob d15	66081	38	Primary Cable	61650
13	Knob d22	66121	39	Fan Guard	66098
14	Pillar	66105	40a	Fuse 6.3A Slow (32x6.3)	64207
15	Pillar	66505	40b	Fuse 2A Slow (32x6.3)	64250
16	HF Coupling Tx PCB	61950	41	Strain Relief	66061
17	HF Generator PCB	61895	42	Terminal Block	64144
18	Gas Hose	66160	43	Fuse Holder	64180
19	Torch Switch Filter PCB	61049	44	On/Off Switch	64053
20	Logo Panel	66725	45	Coupling	63191
21	Mains Filter PCB	61733	46	Aux Tx	64630
22	Solenoid Valve	61703	47	Foot	66501
23	Dins Socket	64274	48	Resistor 1.5k 50W	65969
24	2p Socket	64103	49	DC/AC Com PCB	61896
25	14p Socket	64104	50	Thermal Switch 70C	64215

