

Item	Description	Part Number	Item	Description	Part Number
1	Handle	66109	27	Inductor	61963
2	Lid	62500	28	Tx/Rectifier PCB	61111
3	Shelf	62483	29	Thermal Switch 80C	65775
4	LHS Panel	62349L	30	Base	62009
5	Control Panel Assembly	61339	31	Fuse PCB	61820
6	uP Control PCB	61080	31a	Fuse 16A Slow (32x6.3)	64241
7	LCD Display PCB	61894	32	Thermal Switch 60C	65776
8	Control Panel	62011	33	Primary Inverter PCB	61219
9	Control Panel Label	66751	34	Aux Tx	64637
10	Pot/Switch 100k	65192	35	RHS Panel	62349R
11	Knob d29	66208	36	Strain Relief	66061
12	Knob d15	66081	37	Fan	64182
13	Knob d22	66121	38	Primary Cable	64062
14	Pillar	66105	39	Fan Guard	66098
15	Pillar	66505	40a	Fuse 6.3A Slow (32x6.3)	64207
16	HF Coupling Tx PCB	61950	40b	Fuse 2A Slow (32x6.3)	64250
17	HF Generator PCB	61895	41	Strain Relief	66061
18	Gas Hose	66160	42	Terminal Block	64144
19	Torch Switch Filter PCB	61049	43	Fuse Holder	64180
20	Logo Panel	66750	44	On/Off Switch	64053
21	Mains Filter PCB	61734	45	Coupling	63191
22	Solenoid Valve	61703	46	Aux Tx	64303
23	Dins Socket	64274	47	Foot	66501
24	2p Socket	64103	48	Resistor 1.5k 50W(3)	65969
25	14p Socket	64104	49	DC/AC Com PCB	61896
26	Insulator	66402	50	Thermal Switch 70C	64215

